
www.teknikoffice.co.uk

Teknik



Wake up and smell it.

Canal HeightsCoffee Table

5419233


NOTE: THIS INSTRUCTION BOOKLET CONTAINS <u>IMPORTANT</u> SAFETY INFORMATION.

PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Table of Contents

Assembly Tools Required

Part Identification	3
Hardware Identification	3
Assembly Steps	4-8
Français	9-10
Español	11-12
Safety	13-14
Warranty	15




Part Identification




While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

Α	END (1)	С	TOP SUPPORT (2)
В	TOP (1)	D	END SUPPORT (2)




Hardware Identification







- Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- Fasten the ENDS (A) to the TOP SUPPORTS (C). Use eight 1/2" MACHINE SCREWS (1).




Fasten the ENDS (A) and TOP SUPPORTS (C) to the TOP (B). Use ten 1-3/8" LARGE HEAD SCREWS (2).




Fasten an END SUPPORT (D) to the ENDS (A). Use four 1/2" MACHINE SCREWS (1).



Fasten the remaining END SUPPORT (D) to the ENDS (A). Use four 1/2" MACHINE SCREWS (1).



- Carefully stand your unit upright.
- NOTE: Please read the back pages of the instruction booklet for important safety information.
- This completes assembly. Clean with your favorite furniture polish or a damp cloth. Wipe dry.



⚠ WARNINGPlease use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. *Carefully read the following chart.*

or burning to your formitore or household items. Carefold read the joil wing chart.			
Look out for:	What can happen:	How to avoid the problem:	
Overloaded drawers and shelves.	 Risk of injury. Top-heavy furniture can tip over. Overloaded drawers or shelves can break. 	 Never exceed the weight limits shown in the instructions. Work from bottom to top when loading shelves and drawers. Place the heavier items on the lower shelves or in lower drawers. 	
Placing TVs on furniture items that are not designed to support a television is hazardous.	Risk of injury or death. TVs can be very heavy. Plus the weight and location of the picture tube tends to make TVs unbalanced and prone to tipping forward.	• This product is not designed to support a television.	