

Gets on your couch's  
**good side.**

# Canal Heights End/Side Table

5419229

**NOTE:** THIS INSTRUCTION  
BOOKLET CONTAINS **IMPORTANT**  
SAFETY INFORMATION.

PLEASE READ AND KEEP FOR  
FUTURE REFERENCE.

## Table of Contents

## Assembly Tools Required

Part Identification 3

Hardware Identification 3


Assembly Steps 4-5

Français 6-7


Español 8-9

Safety 10

Warranty 11



No. 2 Phillips Screwdriver  
Tip Shown Actual Size



Skip the power trip.  
This time.


# Part Identification

Now you know  
our ABCs.





⚠ While not all parts are labeled, some of the parts will have a label or an inked letter on the edge to help distinguish similar parts from each other. Use this part identification to help identify similar parts.

A	END (2)
B	TOP (1)
C	BOTTOM (1)
D	BRACE (2)







# Hardware Identification

⚠ Screws are shown actual size. You may receive extra hardware with your unit.




# Step 1

- ✚ Do not completely tighten screws until you have completed assembly.
- ✚ Assemble your unit on a carpeted floor or on the empty carton to avoid scratching your unit or the floor.
- ✚ Fasten the ENDS (A) to the BRACES (D). Use eight 1/2" MACHINE SCREWS (1).
- ✚ Fasten the TOP (B) to the ENDS (A) and BRACES (D). Use eight 1-3/8" FLAT HEAD SCREWS (2).



## Step 2

- ✚ Fasten the BOTTOM (C) to the ENDS (A). Use four 1/2" PAN HEAD SCREWS (3) through the brackets on the ENDS and into the BOTTOM.
- ✚ Completely tighten all of the SCREWS.
- ✚ Carefully stand your unit upright.
- ✚ **NOTE:** Please read the back pages of the instruction booklet for important safety information.
- ✚ This completes assembly. Clean with your favorite furniture polish or a damp cloth. Wipe dry.



## WARNING

Please use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items. ***Carefully read the following chart.***

Look out for:	What can happen:	How to avoid the problem:
<ul style="list-style-type: none"><li>Overloaded shelves.</li></ul>	<ul style="list-style-type: none"><li>Risk of injury.</li><li>Top-heavy furniture can tip over.</li><li>Overloaded shelves can break.</li></ul>	<ul style="list-style-type: none"><li>Never exceed the weight limits shown in the instructions.</li><li>Work from bottom to top when loading shelves. Place the heavier items on the lower shelves.</li></ul>
<ul style="list-style-type: none"><li>Placing TVs on furniture items that are not designed to support a television is hazardous.</li></ul>	<ul style="list-style-type: none"><li>Risk of injury or death. TVs can be very heavy. Plus the weight and location of the picture tube tends to make TVs unbalanced and prone to tipping forward.</li></ul>	<ul style="list-style-type: none"><li>This product is not designed to support a television.</li></ul>