










 <p>Five Star Nylon Base w/ Casters (x1)</p>	 <p>Back Cushion (x1)</p>	 <p>Control Mechanism (x1)</p>	 <p>Screws for control mechanism (x4)</p>	 <p>Insert Cover (x8)</p>
 <p>Pneumatic Lifter (x1)</p>	 <p>Seat Cushion (x1)</p>	 <p>Set of Arm Rests (x2)</p>	 <p>Screws for Armrest (x8)</p>	

ⓘ Please unscrew all screws from cushion before assembly.


STEP 1




STEP 2



STEP 3




STEP 4




*When sitting on the chair, the control lever **MUST** be on your right hand side beneath the seat. It will not work if the lever is on your left hand side.

STEP 5




STEP 6



STEP 7

* Make sure you firmly connect the seat into the pneumatic lifter by using your body weight to bounce on the seat.



OPERATING INSTRUCTIONS FOR SEAT HEIGHT ADJUSTMENT:

To lower the seat height, sit on the chair while pulling the lever upwards.

To raise the seat height, remove your body weight from the seat while pulling the same lever upwards.

To lock your chair in the upright position, push the lever beneath the seat inwards towards the center of the chair.

To unlock the upright lock, pull the same lever outwards.

OPERATING INSTRUCTIONS FOR TENSION ADJUSTMENT:

(Located in the front and center beneath the seat)

Turning the knob counter-clockwise decreases the tension for lighter users. Turning it clockwise increases the tension for heavier users.