

# INSTRUCTIONS FOR SEPARATING TILT MECHANISM/GAS LIFT & 5 STAR BASE

IT IS EASIER FOR 2 PEOPLE TO CARRY OUT THIS PROCESS – 1 PERSON TO HOLD THE CHAIR AND 1 PERSON TO STRIKE WITH THE Mallet

## YOU WILL NEED:

LARGE RUBBER OR PREFERABLY A WOODEN Mallet (A HAMMER WILL NOT BE SUFFICIENT AND MAY CAUSE DAMAGE)

## FIRSTLY:

- RAISE THE CHAIR TO ITS HIGHEST POSITION
- REMOVE THE CASTORS

1) HOLD THE CHAIR SLIGHTLY OFF THE GROUND WITH THE BASE POINTING DOWNWARDS (*IMAGE #1*)



2) STRIKE THE FIVE STAR BASE AS CLOSELY AS POSSIBLE TO THE CENTRAL GAS COLUMN (*IMAGE #2*)



3) TURN THE BASE AND TAP EACH LEG IN TURN UNTIL THE BASE DROPS OFF (*IMAGE #3*)



4) TO REMOVE BASEPLATE OR TILT MECHANISM REPEAT THE EXERCISE BUT STRIKE THE PLATE AT QUARTER TURNS UNTIL THE GAS PUMP IS RELEASED (*IMAGE #4*)



IF YOU ARE UNABLE TO CARRY OUT THIS PROCESS, OR NEED FURTHER CLARIFICATION PLEASE CALL 01234 328804